



Venetian Bead Shop

Silver Foil MultiDots Cube Bracelet



Design by VenetianBeadShop

Basic Black highlighted with Gold.
Easy to make.

Length: 7 1/2 Inches

Tools:
Side Cutters
Crimping Tool

Supplies:
Wire: ~12-14 Inches of 019

Components

Part SKU	Quantity	Item Name
CUBE-10-DOT-S1	7	Murano Glass 10mm Cube with Multi Dots Clear Silver Foil
F-SS-BDCP-SCAL-4	26	.925 Sterling Silver Scalloped Beadcap 4mm
F-SS-CL-LOBR-5090	1	Sterling Silver Trigger Clasp 9mm w/Ring
F-SS-CRIMP-COV3	2	Crimp Covers Sterling Silver 3mm, Per Piece
F-SS-CRIMPTW-019	2	Sterling Silver Twisted Crimp, .019 Wire, Per Piece
F-SS-JRC28-7	1	Sterling Silver 7mm Jump Ring Closed, 21ga, Per Piece
F-SS-WIREPROT021	2	.925 Sterling Silver Wire Protectors .021, Per Piece
RN-06-S3	2	Peridot Green Silver Foil 6mm Round Murano Glass Bead
RN-08-G11	1	Cobalt 8mm 24kt Gold Foil Round, Venetian Glass Bead
RN-08-S3	2	Peridot Green Silver Foil 8mm Round Venetian Glass Bead
RN-08-S4	1	Blue Silver Foil 8mm Round Murano Glass Bead
RN-08-S6	1	Aqua Silver Foil 8mm Round Murano Glass Bead
RN-08-S8	1	Amethyst Silver Foil 8mm Round Murano Glass Bead

Instructions:

Step 1. Begin by cutting your wire. I prefer to use it off the end of my spool to save those couple of inches.

Step 2. If you cut the wire you can begin in the center and string from each side. Since I string directly onto the spool of wire, I begin at one end and string. (I have already laid it out on my beading board for sizing.)

Step 3. The layout is symmetrical only the colors of the 8mm change and you can put in any order you choose.



Venetian Bead Shop

Silver Foil MultiDots Cube Bracelet

Between each bead string a Bead Cap, (including before and after the 8mm)

NOTE: The ending 6mm bead does not have a Bead Cap (because the hole in the beadcap is smaller than our .019 wire).

Step 4. To complete the bracelet string the crimp bead onto the wire, then the wire through the wire protector. At this point, add the clasp Then the wire back through the crimp. Carefully pull the wire taut.

Step 5. On the other end, string the crimp bead onto the wire, then the wire through the wire protector and insert this through a link of the chain.

Step 6. If you have strung this on the spool, then cut the wire about 3-5 Inches longer than the bracelet. Gently tighten the bracelet before crimping the crimp tube and finally cut the extra wire.



HINTS: For Longer:

Add additional 6mm beads, optional continue the pattern.

For Shorter:

Eliminate the ending 6mm beads.

Instructions for Matching Earrings: Click on the Link Below:

[OR-SS-CUBE-MULTI-DOT](#)