



Venetian Bead Shop

Peridot and Pink Watermelon Bracelet 7.25 Inches



Design by VenetianBeadShop

Enjoy the best of Summer with our Peridot and Rubino Bicolor Cubes and Rounds.

Length: 7.25 Inches

Tools:
Side Cutters
Crimping Tool

Supplies:
Wire: ~12-14 Inches of 019
We used BA-JW11SP-10FT

Components

Part SKU	Quantity	Item Name
CUBE-12-BIC-S319	3	Green Rubino Silver Foil Bicolor Cube 12mm, Murano Glass Bead
F-SS-BDCP-SCAL-5	26	.925 Sterling Silver Scalloped Beadcap 5mm
F-SS-CL-LOBSR-11	1	Sterling Silver Oval Trigger Clasp 11.5mm, Solid Ring, Per Piece
F-SS-CRIMP-COV3	2	Crimp Covers Sterling Silver 3mm, Per Piece
F-SS-CRIMPTW-2X2	2	Sterling Silver Twisted Crimp, 2x2mm 1mm ID
F-SS-JRC32-6	1	Sterling Silver 6mm Jump Ring Closed, 20ga, Per Piece
F-SS-WIREPROT031	2	Sterling Silver Wire Protectors .031, Per Piece
RN-12-BIC-S319	4	Green Rubino Silver Bicolor Round 12mm
SCH-RN-06-19	2	Transparent Rubino Pink Murano Glass Round Bead, 6mm
SCH-RN-06-3	2	Transparent Peridot Green Murano Glass Round Bead, 6mm
SCH-ROND-11X7-T19	3	Murano Glass Bead, Rondel, 11x7mm Transparent Pink Rubino
SCH-ROND-11X7-T3	3	Murano Glass Bead, Rondel, 11x7mm Transparent Green



Instructions:

Step 1. Begin by cutting your wire. I prefer to use the wire right off the end of my spool to save those couple of inches.

Step 2. If you cut the wire you can begin in the center and string from each side. Since I string directly onto the spool of wire, I begin at one end and string. (I have already laid it out on my beading board for sizing.)

Step 3. Use a bead cap before and after each bead and follow the picture above for bead placement. (Except we did not use a bead cap between the little 6mms on each end.)

Step 4. To use the wire protectors, put the crimp tube on the wire, then thread through the wire protector. Insert the closed jump ring (or the clasp) in the center and then thread the wire through the crimp tube. I like to feed the wire back through a bead before I cut it. I know all wire makers say you do not have to do this. But I just like the added safety, especially when I am making for someone else to wear.

Step 5. Put the crimp bead over the flattened crimp tube. This has no practical purpose, it just gives your jewelry a finished look.

I started like this!

