



## Purples Machiavelli Sterling Silver Bracelet



Make this bracelet with simple stringing and crimping.

This makes an approximately 7.5 inch bracelet.

**SKILL:** Crimping

**Tools:**

Side Cutter, Crimping Tool

**Want it Longer or Shorter?**

Add additional beads for longer, for shorter switch the beads to a smaller size

**Other Supplies:**

**WS-SFW02410SLV** You can find this on our website or you can use any manufacturer's 024 Sterling Silver Wire.

**BA-216A-106** (Bead Stopper or similar)

### Components

Part SKU	Quantity	Item Name
F-SS-BSM-RN-4	4	Sterling Silver Smooth Round Seamless Beads 4mm, Per Piece
F-SS-BSM-SCR-8	2	Sterling Silver Smooth Saucer Bead, 8mm
F-SS-CL-LOBSW-14	1	Sterling Silver Swivel Lobster Claw Clasp 13.5mm
F-SS-CRIMP-2X2	2	.925 Sterling Silver Crimp Tubes, 2x2mm, Per Piece
F-SS-JRC36-6	1	Sterling Silver 6mm Jump Ring Closed, 19ga, Per Piece
F-SS-TBCV3X38-P7	2	.925 Sterling Silver Diamond Cut Curved Tube Bead, 3mm x 38mm, Diamond Pattern
F-SS-WIREPROT021	2	.925 Sterling Silver Wire Protectors .021, Per Piece
MACH-RN-14-WG85	3	Amethyst and Topaz White Gold Foil Machiavelli Venetian Glass Bead, Round 14mm
RN-06-WG19	2	Rubino White Gold 6mm Round Venetian Glass Bead
RONDELLE-SC-05-S1	2	Rondel Crystal 5mm Silver Plate
RONDELLE-SC-08-S1	6	Rondel Crystal 8mm Silver Plate

### Instructions:

**Step 1.** Cut a 12" length of wire.



## Purples Machiavelli Sterling Silver Bracelet

**Step 2.** You have 2 choices, you can string the bracelet from the center outwards, in which case you will need a bead stopper to be sure your beads don't slide off. After I have laid out my bracelet, I string from one side. So I begin by inserting the wire through one of the Sterling Silver Smooth 4mm Round bead, followed by one of the crimp beads, through the wire protector.

**Step 3.** Before you slide the wire back through the round bead and the crimp bead, insert the Closed Jump Ring in the center of the horseshoe of the wire protector.

**Step 4.** Then slide back through the silver round and the crimp bead. Push the crimp bead up right to the silver round and crimp the two ends of the wire (leaving about  $\frac{1}{4}$  inch of wire).

**Step 5.** Now slide on the first curved tube followed by a 4mm round silver bead.

Step 6. Add a 6mm crystal rondelle.

Step 7. Add the Silver Saucer Bead

Step 8. Add a 8mm crystal rondelle.

Step 9. Add a Machiavelli Bead

Step 10. Add a 6mm Sterling Silver Rubino Bead.

Step 11. Add an 8mm crystal rondelle.

Step 12. Add a Machiavelli Bead

Step 13. Repeat Steps 11, 10, 9, 8, 7, 6, 5, 4

Step 14. Repeat Step 2, replacing the closed jump ring with the swivel clasp.

Step 15. Clip the excess wire to about  $\frac{1}{4}$  inch and stuff it back through the curved tube.