



VenetianBeadShop

Picasso Aqua, Green, Pink Squares Murano Glass Bracelet 7.5"



Design by VenetianBeadShop

Classic design featuring our Picasso inspired little Vela Squares in Aqua, Green and Pink

Length: 7 1/2 Inches

Tools:

Side Cutters
Crimping Tool

Supplies:

Wire: ~12-14 Inches of 019
We used WS-STW01910SLV

Components

Part SKU	Quantity	Item Name
5328-8MM-8S	8	Swarovski 5328 8mm Xilion Faceted Bicone, Amethyst
F-SS-BDCP-SCAL-4	12	.925 Sterling Silver Scalloped Beadcap 4mm
F-SS-BDCP-SCAL-5	12	.925 Sterling Silver Scalloped Beadcap 5mm
F-SS-BSM-RN-4	2	Sterling Silver Smooth Round Seamless Beads 4mm, Per Piece
F-SS-CHBEL13	1 1/2 Inch	3.1mm Sterling Silver Rolo Chain
F-SS-CL-LOBR-5090	1	Sterling Silver Trigger Clasp 9mm w/Ring
F-SS-CRIMP-COV4	2	.925 Sterling Silver Crimp Cover, 4mm
F-SS-CRIMPTW-019	2	Sterling Silver Twisted Crimp, .019 Wire, Per Piece
F-SS-HP1524BE	1	1 1/2 Inch Sterling Silver Headpin 24ga, Ball End
F-SS-WIREPROT021	2	.925 Sterling Silver Wire Protectors .021, Per Piece
PIC-VEL-SQ-18-S3619	6	Green, Aqua, Pink Picasso Silver Foil, 18mm Square, Murano Glass Bead

Instructions:

Step 1. Begin by cutting your wire. I prefer to use it off the end of my spool to save those couple of inches.

Step 2. If you cut the wire you can begin in the center and string from each side. Since I string directly onto the spool of wire, I begin at one end and string. (I have already laid it out on my beading board for sizing.)



Step 3. Use a bead cap (F-SS-BDCP-SCAL-4 for the 8mm Swarovski Crystal and F-SS-BDCP-SCAL-5 before and after the Picasso Beads) before and after each bead except the Swarovski Crystals on each end. There use the 4mm ball. (That is because I like to run the wire back through the first bead and the hole in the bead cap is too small.)

Step 4. Follow the repetitive design with the main 6 focal beads and the 8mm Swarovski beads on each side of the Picasso beads.

Step 5. To complete the bracelet string the crimp bead onto the wire, then the wire through the wire protector. At this point, add the clasp Then the wire back through the crimp. Carefully pull the wire taut.

Step 6. On the other end, string the crimp bead onto the wire, then the wire through the wire protector and insert this through a link of the chain.

Step 7. If you have strung this on the spool, then cut the wire about 3-5 Inches longer than the bracelet. Gently tighten the bracelet before crimping the crimp tube and finally cut the extra wire.

Step 8. With the headpin, insert the 8mm Swarovski Crystal, and wire wrap it through the last loop on your chain extension.

Step 9. Use the Crimp Cover over the twisted crimp bead. It just looks more finished.

Hints:

For Longer:

If you need to make it longer, use a larger Clasp. Or add another Swarovski Crystal on each end, remembering to add the bead caps.

For Shorter:

Eliminate one square and one crystal.