



VenetianBeadShop

Topaz Treasure Miro Bead Necklace 22 Inches



Design by VBS

Get ready for fall with this Topaz necklace. Topaz over 24kt Gold Foil gives this necklace a rich look.

SKILL: Wire Wrapping

Tools:
Side Cutter
Bead Crimp Tool

Supplies:
Wire about 28-30 Inches
We use SoftFlex bronze because we like the way it looks with the Topaz, but you can use wire you already have at home:
WS-SFW02430BRZ

Bead Stoppers: We use Beadalon: **BA-216A-100**
They come in handy always good to have in your supplies.

You can find both of these on our website.

Components

Part SKU	Quantity	Item Name
F-GF-CRIMP-2X2	2	Gold Filled Crimp Tube, 2x2mm, Per Piece
F-GF-WIREPROT031	2	Gold Fill Wire Protector .031 ID, Per Piece
F-PW-SHOOK-AG	1	Gold Plated Pewter S Hook Clasp, Antique Finish, 20mm
F-PW-SPC-HSH04-BG	20	4mm Bright Gold Plated Pewter Heishi Spacer Bead
F-VM-BDCP-PTL-11	10	JBB Vermeil Large Pointed Petal Flower Bead Cap 11mm
MIRO-RN-18-G5	5	Miro Gold Foil Round 18mm Topaz, Murano Glass Bead
RN-12-G5L	2	Light Topaz 12mm 24kt Gold Foil Round, Murano Glass Bead
SCH-RN-06-5	48	Transparent Topaz Murano Glass Round Bead, 6mm
SQ-12-G5	8	Topaz Gold Foil 11-12mm Square Venetian Bead

Instructions:



VenetianBeadShop

Topaz Treasure Miro Bead Necklace 22 Inches

Step 1. We usually string by leaving the wire on the spool as it saves a few inches on every bracelet we make. But if you want to string from the middle outwards, but about 28-30 inches and secure the ends with your bead stoppers.

Step 2. Begin stringing, using the heishe on each side of the Topaz Squares and the Petal Bead Cap on each side of the Miro (large round). Between each bead string 3 of the 6mm transparent Topaz 6mm rounds.

Step 3. Finish one end of the necklace by threading 1 crimp bead then run the wire through the wire protector (both sides) . Place one of the closed jump rings inside the horseshoe of the wire protector.



(You can see the horse shoe and how we slice the rings into the center, then run the loose end of the wire back through the crimp bead.

Step 4. Run the wire back through the crimp bead and I generally run it through a couple of the small 6mm beads. Pull it snugly and crimp using the crimping tool. Then cut the wire close to the bead so it is not visible.

Step 5. On the other end of the necklace, do the same thing.